

1. Unplug the cord going to your radio/ CD player/MP3 player etc. Follow the cable from your device and unplug it from its source (this could be an amplifier or stereo auxiliary port).

2. Plug the cord supplied into this source. Connect the other end of the cable to the 8Ω socket.

3. Plug the power supply into the socket labelled 12VDC. Please check it is connected to a working power point, that the power point is turned on and that the blue light on the front of the unit is lit.

4. Insert The Groove Gallery USB drive into the USB port. The three hours of pre-loaded music tracks on the drive should now be playing through your system.

5. Preview the music by pressing the red speaker button. This will allow you to hear the current playing track. Please note the volume is preset and will not reflect the volume through your system.

6. To adjust the volume turn the dial on the back of the device. Clockwise increases the volume, anticlockwise reduces it.

*Please refer to The Groove Gallery Music Manager Quick Start Guide for instructions on how to customise your own music.*

